


OPSD Skardu Airport

[Login](#)
[Register](#)

VFR Chart of OPSD



IFR Chart of OPSD



Satellite View of OPSD



<http://maps.google.com/maps?ll=35.339491667,75.541394444&t=h&z=16>

Advertisement

ARINC Data Effective 2015-12-10 0901Z

Location Information for OPSD

Coordinates: N35°20.37' / E75°32.48'
 View all [Airports in Northern Areas, Pakistan \(/airports/Pakistan/Northern%20Areas\)](#).
 Elevation is 7316.0 feet MSL.
 Magnetic Variation is 2° East

Operations Data

Airport Use: Open to the Public

Airport Communications

SKARDU Tower: 119.70

Nearby Navigation Aids

ID	Name	Freq	Radial / Range	ID	Name	Freq	Bearing / Range
SNG	SRINAGAR	115.90	023° 89.1	SD	SKARDU	247	322° 0.8
LEH	LEH	115.70	288° 106.2	GT	GILGIT	324	298° 68.5
LLH	LEH	115.70	305° 125.7	SR	SRINAGAR	314	202° 89.5
RN	ISLAMABAD	112.10	046° 158.5	FC	HONGQILAFU	345	356° 101.5

Runway 14/32

Dimensions: 11944 x 98 feet / 3641 x 30 meters

Surface: Hard

Runway 14

Runway 32

Coordinates: N35°21.20' / E75°31.83' N35°19.54' / E75°33.14'

Elevation: 7256

7301

Runway Heading: 145°

325°

Runway 15/33

Dimensions: 6499 x 98 feet / 1981 x 30 meters

Surface: Unknown

Runway 15

Runway 33

Coordinates: N35°20.34' / E75°31.51' N35°19.40' / E75°32.11'

Elevation: 7305

7316

Runway Heading: 150°

330°

Nearby Airports with Instrument Procedures

ID	Name	Heading / Distance
VISR (/airport/VISR/Srinagar-Airport)	Srinagar Airport (/airport/VISR/Srinagar-Airport)	203° 89.4
OPRN (/airport/OPRN/Islamabad-Benazir-Bhutto-International-Airport)	Islamabad/Benazir Bhutto International Airport (/airport/OPRN/Islamabad-Benazir-Bhutto-International-Airport)	227° 159.1